# **DSK-400**

GPI IN/

RS-422

TALLY OUT REMOTE IN1/OUT1 - IN4/OUT4

### セットアップガイド

接続

#### 梱包品

DSK-400 (1)、電源コード (1 セット)、EIA ラック取付金具 (1 セット)、 DSK-RU 接続用変換ケーブル (1)、セットアップガイド (本書)

アース端子

朋栄 HP ヘアクセスし、メールアドレスを登録して、 DSK-400 のページから 取扱説明書/各種資料をダウンロードしてください。 https://www.for-a.co.jp/





24h サービスセンター **03-3446-8575** 365 davs

FORMAT = 1080/59.94p

SYSTEM

**SYSTEM** 

ASPECT = 16:9

### システムモードの設定

初期設定では、システムフォーマットが未設定のため映像が出力されません。以下の手順でシステムフォーマットを設定します。

- (1) MENU ボタンを押してメニューモードに入ります。
- (2) メニューコントロールを回して>SYSTEMを選択し、メニューコントロールを押します。
- (3) メニューコントロールを回して FORMAT を選択し、メニューコントロールを押します。
- (4) メニューコントロールを回してビデオ信号のフォーマットを選びメニューコントロールを押して 確定します。
- (5) メニューコントロールを回して>ASPECTを選択し、メニューコントロールを押します。
- (6) メニューコントロールを回してアスペクト比を選びメニューコントロールを押して確定します。
- (7) MENU ボタンを押します。
- (8) 「Reboot Execution」と表示されるので、メニューコントロールを押して再起動を実行します。設定は再起動後に反映されます。
- ▶ 取扱説明書「6-1-1. システムビデオフォーマット」参照

### 日付、時刻の設定

[SYSTEM]メニューを開き、DATEで日付、TIMEで時刻を設定してください。

▶ 取扱説明書「6-1-9. 日付、時刻」参照

### 3. 出力映像を選ぶ

#### AUX 出力の映像を選ぶ

初期設定では、AUX1の出力にはLINE1のキー映像が出力されます。AUX2の出力にはLINE2のキー映像が出力されます。

AUX1 出力を LINE1 の PGM 映像に変更する場合は、次のように操作します。

[OUTPUT > OUT XPT]メニューで AUX1 を選択します。

L1PG を選択します。

▶ 取扱説明書「6-3-1. AUX 出力映像」参照

OUTPUT > OUT XPT

AUX1 = L1PG

### LINE に SUPER をアサインする

初期設定では、LINE1 には SUPER1 がアサインされています。LINE2 には SUPER2 がアサインされています。

LINE1 映像に SUPER1 と SUPER2 映像を表示する場合は、次のように操作します。 [OUTPUT > ASSIGN LINE1] メニューで SUPER2を ON に設定します。

▶ 取扱説明書「6-3-3. スーパーON/OFF (LINE 出力)」参照

OUTPUT > ASSIGN LINE1 SUPER2 = ON


### 4. SUPER を ON/OFF する

#### SUPER1 を ON/OFF する

SUPER1 ボタンを押して消灯させると、SUPER1 映像が非表示になります。

SUPER1 ボタンを押して点灯させると、SUPER1 映像が表示されます。

SUPER2-4 映像についても、SUPER2から SUPER4 ボタンで同様に ON/OFF できます。



(4) メニューコントロールを回して MENU EXIT TIME を選択し、メニューコントロールを押します。

(5) メニューコントロールを回してタイムアウト時間を選びます。 OFF を選択すると、自動でスタートアップ画面に戻りません。

(6) メニューコントロールを押して設定を確定します。

▶ 取扱説明書「6-10-2. メニュータイムアウト時間」参照


1:0FF 2:0FF 3:0FF 4:0FF

**PANEL** 

MENU EXIT TIME = OFF

#### 使用上の注意

- 指定電圧以外の電源電圧は使用しないでください。
- 必ずアースをとってください。
- 電源コードのプラグおよびコネクターはしっかりと差し込んでください。
- 内部設定を行う場合は必ず電源を切ってから操作してください。
- パネルやカバーを外したままで保管や使用をしないでください。
- 高温多湿、塵埃が多い、振動がある場所などには設置しないでください。 火災や感電の原因になることがあります。
- 内部に水や異物を入れないでください。万一入った場合は、すぐ電源を 切り、電源コードや接続コードを抜いて内部から取り出すか、販売代理 店、サービスセンターへご相談ください。
- 電源が入らない、異臭がする、異常な音が聞こえるときは、すぐに電源を 切り、販売代理店、サービスセンターまでご連絡ください。



# **DSK-400**

## Quick Setup Guide

Packing list DSK-400: 1

AC Cord: 1 set. EIA rack mount bracket set: 1 set Conversion cable for connecting a DSK-RU: 1

Quick Setup Guide: 1 (This guide)

Visit the FOR-A's website, register your email address and download user manuals and other documents from the DSK-400 page. https://www.for-a.com/



**SYSTEM** 


**SYSTEM** 

ASPECT = 16:9




FORMAT = 1080/59.94p


### 1. Connection and System Configuration



- (1) Input SDI signals. (FILL, KEY, LINE IN)
- (2) Connect to SDI signals output. (LINE OUT, AUX OUTPUT)
- (3) Supply power to the DSK-400 using the supplied AC cord.
- (4) Turn the power of the DSK-400 on using the front power switch.



## 2. Setup Procedure




### **Setting Menu Timeout Period**

The DSK-400 automatically exits Menu display when no operation has been performed on the front panel **for 5 seconds** as default setting.


Follow the procedure below to change Menu Timeout Period or turn off.

- (1) "HELLO! DSK-400" is displayed on Menu display when power is turned on. 30 seconds after, "SETUP MENU" is displayed and automatically switched to the start-up display after 5 seconds.
- (2) Press the MENU button to enter menu mode.
- (3) Turn Menu control to select >PANEL and press Menu control.
- (4) Turn Menu control to select MENU EXIT TIME and press Menu control.
- (5) Turn Menu control to select timeout period. When OFF is selected, Menu display is not automatically turned off.
- (6) Press Menu control to confirm setting.
- ▶ See the user manual Sec. 6-10-2. "Menu Timeout Period."



Start-up display





### **Setting System Video Format**

System Video Format is not set in default setting so no video is output. Set the system video format following the procedure below.

- (1) Press the MENU button to enter menu mode.
- (2) Turn Menu control to select >SYSTEM and press Menu control.
- (3) Turn Menu control to select FORMAT and press Menu control.
- (4) Turn Menu control to select a video format and press Menu control to confirm.
- (5) Turn Menu control to select >ASPECT and press Menu control.
- (6) Turn Menu control to select an aspect ratio and press Menu control to confirm.
- (7) Press the MENU button.
- (8) "Reboot Execution" will be displayed. Press Menu control to start reboot. Settings are reflected after the reboot
- ▶ See the user manual Sec. 6-1-1. "System Video Format."

### **Setting Date and Time**

Open the [SYSTEM] menu. Set date under DATE and time under TIME.

▶ See the user manual Sec. 6-1-9. "Date and Time."

### 3. Selecting Output Video

#### Selecting AUX output video

Key video of LINE1 input is output from AUX1 and LINE2 from AUX2 in default setting.

To change AUX1 output to PGM video, follow the procedure below.

Select AUX 1 under the [OUTPUT > OUT XPT] menu. Select L1PG.

▶ See the user manual Sec. 6-3-1. "AUX Output Video."

### **Assigning SUPER for LINE**

SUPER1 is assigned to LINE1 and SUPER2 to LINE2 as default.

To display SUPER1 and SUPER 2 on LINE1, set as below. Set SUPER2 to ON in the [OUTPUT > ASSIGN LINE1] menu.

▶ See the user manual Sec. 6-3-3. "Superimpose ON/OFF (LINE Outputs)."

AUX1 = L1PG

OUTPUT > OUT XPT

OUTPUT > ASSIGN LINE1 SUPER2 = ON

### 4. Superimpose ON/OFF

### **Turning SUPER1 ON/OFF**

Press the SUPER1 button to turn the light off. SUPER1 video will not be displayed.

Press the SUPER1 button to turn the light on. SUPER1 video will be displayed.

Turn ON/OFF SUPER2-4 video in the same way using the buttons SUPER2 to SUPER4.

uttons SUPER2 to SUPER4.

SUPER1 - SUPER4 buttons

#### Precautions

- Operate the unit **only** at the specified supply voltage.
- Ensure the unit is properly grounded at all times.
- Ensure the power cord and connectors are firmly connected.
- **Do not** access circuitry with power applied to the unit.
- Unit should not be operated or stored with the cover, panels, and/or casing removed.
- Unit should not be operated or stored in a humid, dusty, etc. environment. Doing so could result in fire or electrical shock.
- Do not allow fluids, metal fragments, or any other foreign objects to enter the unit. If foreign matter does enter the unit, turn the power off and disconnect the power cord immediately. Remove the material or contact your authorized service representative.
- If you notice any strange smells or noises coming from the unit, turn the power off immediately, disconnect the power cord, then contact your authorized service representative.